



# Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmgsi@KirbyMorgan.com

## Part # 525-373 Anode Kit For the KMB 18/28

### Parts Needed:

Part #	Description	Qty
550-586	Whisker Spacer	4
560-300	Zinc Whisker Anode	2

### Instructions:

1. Replace Kidney Plates with P/N 560-300; Zinc Whisker Anodes and Whisker Spacers with P/N 550-586 Whisker Spacer, use original screws tightened to the torque specification of 12 inch pounds. *See figure 1.*



*Figure 1*

### **NOTICE**

Replace anodes when deterioration interferes with proper fitting or when anodes become loose fitting. Do not paint or coat zincs as this will negate the anodes functionality. Ensure good metal to metal contact when installing the kit and for the duration of the anode kits implementation, failure to do so will render the kit ineffective.